

Scientific Paper:

Polymer 45, 7431-7436, 2004

A promising environmentally-friendly manganese-based catalyst for alkyd emulsion coatings

Z.O. Oyman^a, W. Minga^{a,*}, F. Micciché^{a,b}, E. Oostveen^b, J. van Haveren^b, R. van der Linde^a

^aPolymer Chemistry and Coatings Technology, Laboratory of Coatings Technology, Materials and Interface Chemistry, Eindhoven University of Technology, Den Dolech 2, P.O. Box 513, 5600 MB Eindhoven, The Netherlands

^bDepartment of Polymers, Composites and Additives, ATO B.V., 6700 AA Wageningen, The Netherlands

Abstract:

A manganese(IV) complex [MnMeTACN] containing 1,4,7-trimethyl-1,4,7-triazacyclononane (MeTACN), in the presence of polyamines, significantly accelerated the oxidation of ethyl linoleate (EL) emulsions, and appeared to be a potential environmentally-friendly alternative for Co-based driers that are currently widely used for alkyd emulsion coatings. The polyamines greatly enhanced the catalytic activity of MnMeTACN in decomposing the formed hydroperoxides during the oxidation of EL.

Key-words: Polymer chemistry, polymer materials